

S. Essentials Ext/Dining Table 200/250x100cm White

23704817

Thank you for purchasing the S. Essentials Ext/Dining Table 200/250x100cm White. Before you begin to assemble your new piece of furniture, please check to ensure that all hardware and parts have been supplied. This page lists all contents included in the carton (S).

Follow instructions closely as deviation from them may present a possible safety risk and may void your warranty.


It is recommended that assembly is done on a soft surface such as carpet to avoid any damage.

If you experience any problems with your new purchase, please phone Freedom Customer Service (FCS) on 1300 135 588 (Australia) or 0800 469 327 (New Zealand).

Care Information

Periodically check and re-tighten any fasteners. Avoid direct sunlight as it may cause the product to change colour. Dust the surfaces by using soft and clean cloth. Avoid using harsh abrasives, chemicals or polishes. It is important to remove moist substances immediately. Take care when moving the furniture, do not drag it on the floor to avoid damages.

Hardware (Supplied)




M8*20mm
Part A x 12



M8
Part B x 12




M8
Part C x 12




M8
Part D x 1


Parts



① x 1




② x 1




③ x 1

S. Essentials Ext/Dining Table 200/250x100cm White 23704817

Step 1.




Step 2.




S. Essentials Ext/Dining Table 200/250x100cm White 23704817

Step 3.



Step 4.



S. Essentials Ext/Dining Table 200/250x100cm White

23704817

Finished.

