# Cora LAF Mod 3S+RAF Chaise 24265492

Thank you for purchasing the Cora LAF Mod 3S+RAF Chaise. Before you begin to assemble your new piece of furniture, please check to ensure that all hardware and parts have been supplied. This page lists all contents included in the carton(s).

Follow instructions closely as deviation from them may present a possible safety risk and may void your warranty.

It is recommended that assembly is done on a soft surface such as carpet to avoid any damage. If you experience any problems with your new purchase, please phone Freedom Customer Service (FCS) on 1300 135 588 (Australia) or 0800 469 327 (New Zealand).

#### Care Information


www.freedomfurniture.co.nz


#### Fabric

Periodically check and re-tighten any fasteners. Avoid direct sunlight. Treat spills and stains as soon as they occur. Gently scrape any soil or mop any liquid from the surface of the fabric, apply proprietary cleaning agents strictly according to instructions to remove the residue of the spill. Do not saturate the fabric or interior with water or other cleaning liquids. May be spot cleaned with dry cleaning solvent. Pilling can occur occasionally as a result of normal daily wear and should not be considered as a fault. Fibre pills removed by a battery operated pilling tool available from most haberdashery stores.

#### Leather

Periodically check and re-tightened any fasteners. Dust weekly with a clean dry duster. Protect from direct and indirect sunlight. Maintain at least 30cm between your leather furniture and heat sources. Use Freedom recommended leather care products designed for your Corrected Grain leather. Use care products strictly in accordance with the manufacturers instructions. Use a leather cleaner to remove dirt and body oil build up. Use a protection cream to guard the leather from stains and help maintain its suppleness.






## Cora LAF mod 3S+RAF chaise


## 24265492

Step5



### Step6

! Two people required to orientate sofa



Footrest Retract
Press the rear button found on
the side of the sofa until the
footrest returns to the closed
position.

Footrest Recline
Press the front button found on
the side of the sofa. The footrest
will extend out. Keep the button
pressed until it reaches the
desired position.

mechanized furniture or operate the mechanism.

Legrest folds down on closing so that a child could possibly be injured. Always leave in an upright and closed position. keep hands and feet clear of mechanism. Only the occupant should operate it.

www.freedom.com.au www.freedomfurniture.co.nz

Page 3 of 3

