

COSH CEILING PENDANT MEDIUM

24301879, 24307406, 24301930, 24307413

FREEDOM

Thank you for purchasing the **Cosh Ceiling Pendant Medium**. Before you begin to assemble your new lamp, please check to ensure that all hardware and parts have been supplied. This page lists all contents included in the carton(s).

Follow instructions closely as deviation from them may present a possible safety risk and may void your warranty.

It is recommended that assembly is done on a soft surface such as carpet to avoid any damage. In the interest of safety, Freedom recommends all pendants to be installed by a licenced electrician.

If you experience any problems with your new purchase, please phone Freedom Customer Service (FCS) on 1300 135 588 (Australia) or 0800 469 327 (New Zealand).

Care Information:

Wipe down surfaces with a clean cloth weekly.

Replacing the bulb:


switch off power supply and allow the bulb and pendant to cool down before replacing the bulb(s).
Bulb: E27 MAX 40W Incan or E27 MAX 10 LED required (not included).

Specifications:

230-240V AC 50Hz

IP20-Indoor Use only




E27 Max. 40W 

(bulb not included)

E27 Max. 10W 


Class II protection

Hardware(Supplied)



M4*L25mm

Ⓐ x2



Ø6*L25mm


Ⓑ x2

COSH CEILING PENDANT MEDIUM


24301879, 24307406, 24301930, 24307413

FREEDOM


①




②




③




④




⑤





⑥



⑦



 **E27 Max. 40W**
 **E27 Max. 10W LED**