Thank you for purchasing the TILDA Buffet. Before you begin to assemble your new piece of furniture, please check to ensure that all hardware and parts have been supplied. The following page lists all contents included in the carton(s).

Follow instructions closely as deviation from them may present a possible safety risk and may void your warranty.

It is recommended that assembly is done on a soft surface such as carpet to avoid any damage.

If you experience any problems with your new purchase, please phone Freedom Customer Service (FCS) on 1300 135 588 (Australia) or 0800 469 327 (New Zealand).

Care Information

DO


- · Use tablecloths, table runners and coasters to help protect surfaces from scratching.
- · Dust once a week using a soft cloth or similar duster.
- · Only use freedom recommended care products as many supermarket polishes and waxes contain high levels of silicon and petroleum distillate which can damage the surface.
- · Polish your furniture every 3 to 6 months, making sure the surface is free from dust before you start.

DON'T

- · Avoid placing hot or wet items directly on the surface as they can leave marks which are difficult to remove.
- · Avoid direct sunlight, as this will cause colour change. If the furniture is in direct sunlight, move items like vases around to avoid spotting.
- · Avoid applying too much polish as this will build up and need to be removed with a wood-cleaning product

GENERAL


Periodically check and re-tighten all fasteners. When moving furniture always lift it rather than drag it.



DAS Rev 1



Hardware (Supplied)






30 min



This assembly requires two persons

Tools Required (Not Supplied)

DRILL SHOULD
ONLY BE USED
TO ASSIST IN
ATTACHING
ANTI-TILT STRAPS TO WALL




www.freedom.com.au www.freedomfurniture.co.nz




Parts

			$\left[\bigvee \right]$
1	1	1600x400x565	
2	2	185x189x35	
3	2	185x189x35	
4	1	1400x50x35	
5	1	1035x368x38	
6	1	495x368x18	












Step 2







www.freedom.com.au www.freedomfurniture.co.nz FREEDOM











www.freedom.com.au www.freedomfurniture.co.nz FREEDOM







www.freedom.com.au www.freedomfurniture.co.nz FREEDOM

24387842

Step 7







NEXT STEP: Attach anti tilt strap or bracket to wall

WARNING:

To prevent your furniture from tilting forward and possibly causing property damage or personal injury it is recommended that you <u>Securely attach the anti-tilt straps or brackets provided to your wall using appropriate fixings</u>

IMPORTANT:

- <u>DO NOT</u> place toys or other child appealing items on top of this furniture
- AVOID fully opening all drawers at the same time
- <u>DO NOT ALLOW</u> Small children to climb onto Drawers, shelves or to swing from open doors

CAUTION:

For your safety when attaching the anti-tilt fixings;


- Check for any electrical wires or plumbing inside the wall before drilling any holes (if you are unsure please seek professional advice from a qualified tradesman)
- Walls are constructed from different materials eg; Masonry (solid brick) or plaster board lined cavity walls (hollow).


It is important that you use the appropriate wall fixings for your wall type.

(Your local hardware store will have the necessary drills and fixings and can offer advice if needed)



Step8





IMPORTANT!









24387842


Step 9







Step 10







TILDA Buffet 24387842 Step 11 Gx6 Ø3,5x16 mm Ø7x2 mm





24387842

Step 12

