Thank you for purchasing the JAXON Dining Table. Before you begin to assemble your new piece of furniture, please check to ensure that all hardware and parts have been supplied. The following page lists all contents included in the carton(s).

Follow instructions closely as deviation from them may present a possible safety risk and may void your warranty.

It is recommended that assembly is done on a soft surface such as carpet to avoid any damage.


If you experience any problems with your new purchase, please contact Freedom Customer Service via livechat@freedom.com.au (Australia) or 0800 469 327 (New Zealand)

Care Information

Periodically check and re-tighten any fasteners. Dust weekly using a soft, clean cloth. Do not use harsh abrasives, chemicals or polishes containing silicone. Avoid direct sunlight as this may cause the timber to change colour. It is important to remove moist substances immediately.

Always carefully lift furniture when moving it around the home and never drag. Use floor protectors on the bottom of furniture (like tables and chairs) to minimise damage to floor coverings.


Use coasters, place mats, tablecloths and table runners to protect furniture surfaces from heat and stains



NA Pay 1



Hardware (Supplied)







30 min



This assembly requires two persons

Tools Required (Not Supplied)




www.freedom.com.au www.freedomfurniture.co.nz



Parts

			\bigvee
1	1	2000x950x29,5	
2	1	708x865x160	
3	2	708x805x160	





www.freedom.com.au www.freedomfurniture.co.nz FREEDOM

JAXON Dining Table


24495547/24429412


Step 1






Step 2






www.freedom.com.au www.freedomfurniture.co.nz FREEDOM

Step 3






www.freedom.com.au www.freedomfurniture.co.nz Page 5-6 FREEDOM


JAXON Dining Table

24495547/24429412

Step 5



Step 6



www.freedom.com.au www.freedomfurniture.co.nz FREEDOM