

MARINER FLOOR LAMP

24529716

Thank you for purchasing the MARINER FLOOR LAMP. Before you begin to assemble your new lamp, please check to ensure that all hardware and parts have been supplied. This page lists all contents included in the carton(s).

Follow instructions closely as deviation from them may present a possible safety risk and may void your warranty. It is recommended that assembly is done on a soft surface such as carpet to avoid any damage.

If you experience any problems with your new purchase, please contact Freedom Customer Service via livechat@freedom.com.au (Australia) or 0800 469 327 (New Zealand).

Care Information

Periodically check and re-tighten all fasteners. Wipe down surfaces using a clean cloth weekly. If the external flexible cable or cord is damaged it shall be exclusively replaced by professional. Ensure screws are fastened firmly as small parts may present a choking hazard.

Replacing the bulb:

Disconnect the plug from the electrical supply and allow the bulb and lamp to cool down, replace the bulb with an **E27 Max. 60W**(CFL 11W)X1 required (not included).

Specifications:

220-240V ~ 50Hz

IP20-Indoor Use only

E27 Max. 60W  (bulb not included)

E27 Max. 11W 

Class II protection

