### Inez Bed - Queen

Pewter - 24605281 / 24605304 / 24605298 Snow - 24605236 / 24605243 / 24605298

Thank you for purchasing the Inez Bed. Before you begin to assemble your new piece of furniture, please check to ensure that all hardware and parts have been supplied. This page lists all contents included in the carton(s).

Follow instructions closely as deviation from them may present a possible safety risk and may void your warranty.

It is recommended that assembly is done on a soft surface such as carpet to avoid any damage.

If you experience any problems with your new purchase please contact Freedom Customer Service via www.freedom.com.au(AUS) and www.freedomfurniture.co.nz (NZ)


### Care Information


#### DO

- Vacuum regularly with a soft upholstery attachment. Dirt combined with body moisture can produce a grime discolouration to the fabric. Vacuuming will also remove grit that can also wear the fabric resulting in damage to the yarns.
- Use a professional dry cleaning service at least once a year to keep the fabric looking good. Temporary pilling can happen with some fabrics. This isn't considered a fault and can be removed using a de-piling machine.


#### DON'T


- Don't place the fabric in direct sunlight or near heaters as this will fade and damage the fabric. Use curtains and blinds to protect your furniture from direct sunlight through windows.
- Don't pull loose sewing threads, cut them instead.





www.freedom.com.au www.freedomfurniture.co.nz Page 1 of 5 FREEDOM







# Inez Bed - Queen

Pewter - 24605281 / 24605304 / 24605298 Snow - 24605236 / 24605243 / 24605298

Step 5.





# Inez Bed - Queen

Pewter - 24605281 / 24605304 / 24605298 Snow - 24605236 / 24605243 / 24605298

Step 7.

