

SONATA MODULAR ARMLESS 1S NATURAL 24650557

Remove cushions
when not in use



Thank you for purchasing the SONATA MODULAR ARMLESS 1S NATURAL. This page lists all contents included in the carton(s).

Follow instructions closely as deviation from them may present a possible safety risk and may void your warranty.


If you experience any problems with your new purchase, please contact Customer Service via the website www.freedom.com.au or www.freedomfurniture.co.nz

Care Information

This product is suitable for Full Outdoor Use - Remove cushion when not in use

This refers to sofas and pieces where the furniture can be kept outdoors. Take care to remove cushions and store inside or in a dry area when not in use. Please read the care label for more information.

- Furniture made with Olefin, man-made wickers and aluminium can be simply washed down with warm soapy water and left to dry naturally. Do this at least twice a year.
- To prolong the products life span, store in a dry location when not in use or during periods of inclement weather.



Make sure the
hook and loop
tape aligns with
each other

