

# AVA BED

queen / king / nz king

24522328 / 24522267 / 24522199 / 24522168 / 24522397 / 24522373  
24522304 / 24522274 / 24522205 / 24522151 / 24522380 / 24522359  
24522218 / 24522250 / 24522175 / 24522182 / 24522403 / 24522366  
24522335 / 24522281 / 24522236 / 24522212 / 24522434 / 24522427

Thank you for purchasing the Ava Bed. Before you begin to assemble your new piece of furniture, please check to ensure that all hardware and parts have been supplied. This page lists all contents included in the carton(s).

Follow instructions closely as deviation from them may present a possible safety risk and may void your warranty.

It is recommended that assembly is done on a soft surface such as carpet to avoid any damage.

If you experience any problems with your new purchase please contact Freedom Customer Service via [www.freedom.com.au](http://www.freedom.com.au) (AUS) and [www.freedomfurniture.co.nz](http://www.freedomfurniture.co.nz) (NZ)

## Care Information

### DO


Vacuum regularly with a soft upholstery attachment. Dirt combined with body moisture can produce a grime discoloration to the fabric. Vacuuming will also remove grit that can also wear away the fabric. When you can, rotate the cushions to even out the wear. Use arm caps to help the fabric last longer. Follow the upholstery care instructions label attached to the bed. Use a professional dry cleaning service at least once a year to keep the fabric looking good. Leave any removable covers on during cleaning to minimise shrinking. Temporary pilling can happen with some fabrics. This isn't considered a fault and can be removed using a de-piling machine.

### DON'T

Don't place the fabric in direct sunlight or near heaters as they can fade and damage the fabric. Use curtains and blinds to protect your furniture from direct sunlight through windows.


Don't pull loose threads, cut them instead.

## Hardware (Supplied)




JCBB SCREW M8 x 30mm  
(Pre-attached)

8 x Part G



ALLEN KEY M8

1 x Part H




# AVA BED


queen / king / nz king

24522328 / 24522267 / 24522199 / 24522168 / 24522397 / 24522373  
24522304 / 24522274 / 24522205 / 24522151 / 24522380 / 24522359  
24522218 / 24522250 / 24522175 / 24522182 / 24522403 / 24522366  
24522335 / 24522281 / 24522236 / 24522212 / 24522434 / 24522427

Step 1.



Step 2.



# AVA BED

queen / king / nz king

24522328 / 24522267 / 24522199 / 24522168 / 24522397 / 24522373  
24522304 / 24522274 / 24522205 / 24522151 / 24522380 / 24522359  
24522218 / 24522250 / 24522175 / 24522182 / 24522403 / 24522366  
24522335 / 24522281 / 24522236 / 24522212 / 24522434 / 24522427

Step 3.

