



Canvas is a natural product and will at times stretch due to weather conditions or if it has been pressed by an object. If canvas is stretched or has crease marks along the front face inner frame edge follow these simple steps to fix.




Take the canvas off the wall and turn upside down placing it on a smooth flat surface. Make sure the artwork is facing down and the back of the canvas is visible.



You will need a spray bottle filled with water or a damp clean sponge and towel/cloth.



With the back of the canvas visible, lightly spray or dampen the back of the canvas effected area. Lightly wipe off excess water with the cloth and allow to dry for a approximately 5 minutes.



Check that the canvas has dried and inspect the effected area from the front of the canvas. If the canvas has not repaired itself repeat the process and allow to completely dry.